

MONTAGE - UNTERHALT INSTRUCTIONS ZU BEACHTEN MIT BEZUG AUF DIE GARANTIE.

1. DIE MONTAGE, DER ANSCHLUSS UND DAS AUSSTESTEN DER LEUCHTEN SOLL IMMER VON EINEM ZUSTÄNDIGEN ELEKTRO-INSTANTANETEUR AUSGEFÜHRT WERDEN.

2. DIESE LEUCHTEN MÜSSEN INSTALLIERT, ANGESCHLOSSEN UND GETESTET WERDEN NACH DER ALLGEMEINEN NAZIONALEN REGLEMENTATION ÜBER DIE ELEKTRISCHE INSTALLATIONEN (BELGIEN, A.R.E.; DEUTSCHLAND: DIN VDE 0100 TEL. 559.42, ...; DIESE AUFSTELLUNG GESCHIEHT DURCH EXEMPLATIVEN TITEL UND KANN NICHT ALS LIMITATIV ODER EXHAUTIV BETRACHTET WERDEN).

3. DIE TECHNISCHE GEBRAUCHSANWEISUNG GEHÖRT ZU DEN ALLGEMEINEN VERKAUFSBEDINGUNGEN VON TAL N.V.

4. DER ELEKTRO-INSTANTANETEUR IST VERANTWORTLICH FÜR DAS VERWENDEN VON CE UND EMC GEFUHRTE VERBODENSGERÄTE.


5. DIE LAMPE(-N) SOLL(-EN) IMMER SERH VORSICHTIG ERSETZT WERDEN.

6. VORSICHT: MAN DARF NIE DIE LAMPE MIT DEN NAKTEN HÄNDEN BERÜHREN, MAN SOL IMMER EINEN TUCH BENUTZEN !

With M10 base 'round 3' and M10 base PRO '600', '900', '1200' for surface mounting on ceiling

With M10 base 'kosmos' and 'kosmos heavy load' for hollow ceiling for electrical connection above ceiling

- ③ Switch on mains power supply



- With M10 base 'kosmos' and 'kosmos heavy load' for hollow ceiling for electrical connection above ceiling
- drill 1x hole Ø55mm
- installation depth: 60mm

see seperate manual