rond

floor box Ø60
installation instruction

1





build up all floor layers except the top concrete layer. leave an opening of at the location of the floor socket.

optional: floor box level support



optional use floor box level support:

version	SKU	dimensions
single	8800-2525	100x100 mm
double	8800-2526	200x100 mm

2



fill the hole with screed

3



insert the preflex in the floor box

4



insert the floor box in the screed and level the top of the box

5

build up the final concrete layer

6



gently remove the plastic lid

7

connect the socket (not included) and click it in the holder
compatible with **trimless** retro/easy/backlit type E/F socket modules

8



insert the showering

9

install the cover plate Ø60 of choice (sold separately)

10



for access remove the cover plate with a plug

thank you for choosing rond

rond.io Stove NV – Handelsstraat 19 - 9630 Veurne – Belgium

Installation must be done by skilled professionals only and instructions must be followed at all times. Warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair a product.